



Instructions for adding or replacing the side reflective tape on the StowAway Max Carrier. r0511

1. Remove existing reflective tape, if any.
2. Remove any residual adhesive using duct tape as a tack.
3. Clean the smooth area with rubbing alcohol to remove any dirt or remaining adhesive.
4. Apply the new reflective tape, starting toward the back of the box (radiused section) and wrapping the tape toward the front.
5. Apply the second piece of tape, starting at the corner, and wrap it around the box to the taillight.
6. Do the same for the other side of the box.